

Assembly Instructions For The Porch Rocker

Tools Needed:

Phillips Head Screwgun

Parts List:

Seat Assembly (1)
Back Assembly (1)
Left Arm & Leg Assembly (1)
Right Arm & Leg Assembly (1)
Rockers (2)

Hardware:

1/4" x 2-1/2" Phillips Bolts (6)
1/4" x 1-1/2" Phillips Bolts (4)
3" Phillips Screws (4)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Place the seat assembly on edge on the floor with the front slat facing down. Place the arm assemblies on the proper sides (with the curved part of the arm on the outside) and line up the holes in the legs with the holes on the side of the seat assembly. Insert a 2-1/2" bolt in each hole and semi-tighten only. **(Do not fully tighten any bolts until all bolts are in the proper holes).**
- Step 3** Lay the back assembly down between the arms. Line up the holes on the back of the arm with the holes on the back assembly and fasten with a 2-1/2" bolt. Now take the 3" screws and fasten the bottom of the back assembly to the back of the seat assembly in the predrilled holes. (You might have to loosen the arm and leg assembly slightly so the back fits in between the arms).
- Step 4** Now attach the rockers to the leg assemblies by lining up the holes in the rockers with the holes in the legs. Fasten with the 1-1/2" bolts. Make sure you have the longer end of the rocker at the back of the chair. Now fully tighten all bolts.