

Entertaining Table Assembly Instructions

Item: ELY5820CVD, ELY4820CVD

The item can be found on
www.CedarwoodFurniture.com

Call 877-595-8537 to order

Hardware

- 12- 2 1/2" Screws
- 4- 1 1/4" Screws
- 6- 2" Screws


Materials

- 1- Top
- 2- Leg Sections
- 2- Shelves


Tools Needed

- Drill
- Hammer for light tapping
- #2 Square Head Bit (provided)

Lay top upside down on a clean, flat surface. (We recommend using the box the product came in.) Attach the legs using three 2" screws on each leg. (see figure 1)




Put one 1 1/4" screw into each leg where the pocket hole is on the side rail. (see figure 2)



Put the 1st shelf in between legs where the pre-drilled holes are. Attach them with three 2 1/2" screws on each side.

Now put the second shelf down between the legs where the pre-drilled holes are. Attach the shelf with three 2 1/2" screws on each side. (see figure 3)



Fully Assembled Red Cedar Teagan Table