

# The Woodhaven® Courtyard™



## Assembly Instructions

**IMPORTANT PLACEMENT:** To prevent the possibility of this product tipping over, it **MUST** be placed on a hard, level surface such as concrete or heavy concrete stepping stones.


NEVER PLACE THIS RACK ON DIRT OR ANY OTHER UNSTABLE SURFACE. CHILDREN SHOULD NOT BE ALLOWED TO PLAY ON THE RACK.

The item can be found on  
[www.CedarwoodFurniture.com](http://www.CedarwoodFurniture.com)

Call 877-595-8537 to order

### Step 1:

On the ground, bolt the bottom rail to the two end sections using the large bolts, washers, and nylon locking nuts.



### Step 2:

Slide bottom of parts from step one over tubes on base plate and secure with the small bolts. Holes in base plate can be used to secure the rack to concrete or wood.



### Step 3:

Install short brace between the parts from step one using the holes toward the top of the rack. Use the large bolts,

