



AMPLIPOWER60+™

EASY-DIAL PHONE WITH VOLUME AND TONE ADJUSTMENT
TELEPHONE MULTIFONCTIONS A GRANDES TOUCHES
TELÉFONO MULTIFUNCIONES CON TECLAS GRANDES



English



Caution: This telephone product is specifically designed for people with hearing difficulties and is provided with a handset earpiece volume control for individual requirements. Due care must be taken by all users that the handset earpiece volume control is set to the lowest level acceptable by each respective user. Care should therefore be exercised to ensure that any new users are familiar with this requirement.

Attention: Ce telephone peut etre destine aux personnes ayant des problemes d'audition. Il possede un ecouteur a volume variable. A la premiere utilisation, assurez vous que le bouton de reglage du volume soit positionne sur la position volume minimum. Les personnes malentendantes pourront par la suite augmenter le volume pour l'adapter a leur audition.

Precaución: Este producto telefónico ha sido específicamente diseñado para personas con dificultades de audición, y lleva un control de volumen a la altura del auricular para adaptarlo a las necesidades individuales. Habrá que tener un cuidado especial de ajustar el control de volumen al nivel mínimo aceptable por cada usuario respectivo. Deberá asegurarse de que todos los nuevos usuarios se familiarizan con este requisito.

CONTENTS

INSTRUCTIONS	4
DESCRIPTION	5
SETTING UP	
- Connecting the telephone	6
- Alarm and ring options	6
- Ringer settings	6
- Tone/Pulse switch (T/P)	7
- Time break recall switch (600/100)	7
- Hotel message waiting switch	7
- Wall mounting	8
USING THE PHONE	
- Answering incoming calls	9
- Volume and tone receiving	9
- Making a call	10
- Last number redial	11
- Recall, * & # buttons	11
- Mute button	11
- Storing telephone numbers	12
- Dialling stored numbers	12
REGULATORY COMPLIANCE	13
GUARANTEE	15

INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS!

Congratulations on purchasing your Geemarc AMPLIPOWER60+™ telephone. This is a multifunction telephone which offers features such as hands free use, phone book, caller display* and voice announcing.

It is important that you read the instructions below in order to use your Geemarc telephone to its full potential. Keep this user guide in a safe place for future reference.

This guide explains how to use the following telephone: AMPLIPOWER60+™


*To use the caller display facility, you must subscribe to your network provider's caller display service.

Unpacking the Telephone

When unpacking the telephone, you should find the following in the box:

- 1 AMPLIPOWER60+™ unit
- 1 AMPLIPOWER60+™ handset with curly cord
- 1 Mains power adaptor
- 1 Telephone line cord
- 1 User Guide

DESCRIPTION



(*) : For these optionals accessories, consult the retailer (see contact details at the end of this manual)

Caution: Repeated incremental exposure to amplification levels greater than 18dB may be harmful to individuals without hearing disabilities. Therefore, do not remove the warning label attached to the back of the handset. If it is likely that a visually impaired person will use the telephone, securely attach the provided warning printed in Braille to the back of the handset.

Note: In standard use, the amplifier turns off whenever you hang up the telephone. This is a useful feature if many people use the phone. If you want the amplifier to always remain on, slide the Volume Reset Override switch on the back of the phone to ON.

SETTING UP

1 - CONNECTING THE TELEPHONE

- Connect the handset cord
- Open the battery door by unscrewing the retaining screw. Insert 4 x AAA alkaline batteries. Snap the battery door in place.



In case of power failure, batteries are required for the ring.

- Connect the line cord .
- Connect the PTT plug to the wall socket.
- Connect the 12V DC adaptor cord to the telephone.
- Connect the 12V DC adaptor to your wall socket (**).

(**) Classified “hazardous voltage” according to EN60950 standard.

2 - ALARM AND RINGER OPTIONS

A 3 position switch located on the right side of the phone allows the settings below:

- **0** : Only the ringer is activated.
-  : Ringer and shaker are activated.
-  : Ringer and strobe flash are activated.

3 - RINGER SETTINGS

A switch located on right side allows the ringer to be switched HI,LOW,OFF:

 : Off,  : Low,  : Hi

Your phone comes with the ringer switched to «High» and the melody set to «6».

SETTING UP

	Low	Middle	High
Melody 1	1	2	3
Melody 2	4	5	6 (by default)
Melody 3	7	8	9

If you don't like the ringer melody, you can choose a new one by changing the settings as follow:

- Lift the handset.
- Press **PROG** button.
- Press **#** button.
- Press any button 1 to 9.

Ringer will be activated on next call.

4 - TONE/PULSE SWITCH (T/P)


The Tone/Pulse switch is factory pre-set to Tone position (T). In the US, all telephone exchanges now use Tone dialling. If your phone does not dial out, it is probably being used from an older private switch-board (PBX). In this case, the Tone/Pulse switch must be moved to Pulse.


5 - TIME BREAK RECALL SWITCH (600/100)

For the US, the TBR switch is factory pre-set to 600ms. It can be switched to 100ms for other locations or PBX's.

6 - HOTEL MESSAGE WAITING SWITCH

These are used with the new services provided on hotel network.

A switch  located behind your phone allows to set **ON** the hotel message waiting function.

When the switch is setting **ON** and when you receive a message, the red light  is lit to inform you that you have a message on phone .

SETTING UP

7 - WALL MOUNTING

To wall-mount your telephone, slide out the clip, turn around and slide back into the wall mounting position (located in the base unit, just below the ear piece). This will ensure that the handset stays firmly in position. Make 2 holes in the wall 80mm apart, insert the wall plugs and the wall mounting screws. The screws should protrude from the wall by 6-7 mm. Place the phone onto the screw-heads and slide down to secure.

If you are using this telephone with a hearing aid, set your hearing aid to the “T” setting.

USING THE PHONE

1 - ANSWERING INCOMING CALL

Without headset:

- When an incoming call is received, the phone will ring, to answer the call lift the handset and speak.
- On completion of the call, carefully replace the handset in the cradle to release the line.

With headset (option):

- When an incoming call is received, and if you wish to answer the call with the headset, press the **SPKR** button and speak.
- On completion of the call, press the **SPKR** button again to release the line.

In handsfree mode:

- When an incoming call is received, the phone will ring, to answer the call press the **SPKR** button.
- On completion of the call, press the **SPKR** button to release the line.

2 - VOLUME AND TONE RECEIVING ADJUSTMENT



You can increase the volume and adjust the receiving tone according to your own hearing requirements. The button +60dB allows extra-receiving and tone functions to be activated or not during the conversation. When the function is activated, the red light of extra receiving and tone function located near the button +60dB is lit. Adjust the **TONE** and **VOLUME** buttons to remove.

Note:

When the switch located behind the phone is **ON**, the extra-receiving and tone functions are automatically activated each time you use the phone. When the switch is switched **OFF**, you will need to activate the function by pressing the button +60dB. Tone and volume adjustment 30dB to 60dB is only activated when the button **ON**.

USING THE PHONE

When this button is set to **OFF** only the volume can be adjusted from 0dB to 20dB.



3 - MAKING A CALL

Without headset:

- Lift the handset.
- Await the dial tone and dial required number.
- On completion of the call, carefully replace the handset in the cradle.

With headset (option):

- Press the **SPKR** button.
- Await the dial tone and dial required number.
- On completion of the call, press the **SPKR** button again to clear the line.

USING THE PHONE

In handsfree mode

- Press the **SPKR** button.
- Await the dial tone and dial required number.
- On completion of the call, press the **SPKR** button to release the line.
- If your correspondent doesn't answer your call, press the **SPKR** button again to release the line.

Note:

- To deactivate the handsfree function during a call, lift the handset. To activate the handsfree function during a call, press the **SPKR** button and place the handset on the cradle.
- During a call in handsfree, you can adjust the speaker volume to a desirable level.
Simply use the slide control VOLUME located on the left of the unit.

4 - LAST NUMBER REDIAL

- Lift the handset.
- Await the dial tone and press **REDIAL** button.
- The previously dialled number will be automatically redialled (not in use for memory numbers).

5 - FLASH, * & # BUTTONS

These are used with the new services provided on digital exchanges. For details please contact your network operator.

6 - MUTE BUTTON

If you wish to speak privately to someone else in the room without your caller overhearing, press and hold the button **MUTE**. You will still be able to hear the callers but they cannot hear you during the mute operation. To resume normal conversation, release the **MUTE** button.

USING THE PHONE

7 - STORING TELEPHONE NUMBER

Your phone can store 12 direct memories including 3 priorities numbers (21 digits maximum for each memory).

For example, the 3 priority  memories allow you to store the 3 numbers below:

- Local, Police station,
- Your doctor
- Family

It is recommended to store these numbers during installation


To store a number please follow instructions below:

- Lift the handset.
- Press **PROG** button .
- Press M1, M2, ..., or M9 or one of 3 priorities numbers to store your number.
- Dial the number.
- Press **PROG** button again.

Numbers will be lost after a few hours if you disconnect your phone. Entering a new number in memory will automatically erase the previous number.

Note: To dial an international number there should be a pause between the country code and the rest of the number. To enter a pause, press the REDIAL button.

8 - DIALLING STORED NUMBER

- Lift the handset and await the dial tone.
- Press appropriate button M1, M2, ..., or M9 or one of the 3 priorities  numbers , the stored number will be dialled automatically.

To register your stored phone numbers, use the index card located under the base.

REGULATORY COMPLIANCE

- This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.
- All applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e. RJ11C) in the package with each piece of approved terminal equipment.
- A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirement adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.
- The REN is useful to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices you may connect to your line, as determined by the REN, you should contact your local telephone company to determine the maximum REN for your calling area.
- If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your rights to file a complaint with the FCC if you believe it is necessary.
- The telephone company may make changes in its facilities, equipment, operation or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
- This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs. This equipment is hearing aid compatible.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

REGULATORY COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Some cordless telephones operate at frequencies that may cause interference to nearby TV's and VCR's; to minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR; and, if interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

- If trouble is experienced with this equipment, for repair or warranty information, please contact our customer service staff at: 248-577-5400

If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

- Please follow instructions for repairing if any; otherwise do not alter or repair any part of device except as specified.

Opening the equipment or any attempt to perform repairs will void the warranty. For service or repairs, call 248-577-5400

- Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation for information.

- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this telephone equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

- This equipment is hearing aid compatible.

GUARANTEE

Sonic Alert warrants the phone against any defect in materials or workmanship for the period of one year from the date of purchase.

Should you experience a problem, contact our customer service department.

Be sure to save your sales receipt as proof of purchase date should you need warranty service.

Within a period of one year from purchase date, Sonic Alert will repair or replace (our discretion) your phone at no cost, if a defect in materials or workmanship is found. If we elect to replace your phone, we may replace it with a new or reconditioned product of the same or similar design.

Repair or replacement will be warranted for a period of 90 days or the original time on the original warranty, whichever is longer.

The warranty does not cover accidents, negligence or breakage to any parts. This includes shipping damage, failure to follow instructions, misuse, fire, floods, use of incompatible accessories, Acts of God or failure in your phone service carrier's line service. The product must not be tampered with or taken apart by anyone who is not an authorized Sonic Alert representative. Tampering with the phone will void any written or implied warranties.

GUARANTEE

Sonic Alert shall not be responsible for loss of time, inconvenience, property damage caused by your phone or any other accidental or consequential damages

Warranty service is available only with proof of purchase.

Simply send the AMPLIPOWER60+™ (postpaid) and a copy of your sales slip as proof of purchase to:

Sonic Alert Inc., 1050 E. Maple Road, Troy MI 48083

IMPORTANT : YOUR RECEIPT IS PART OF YOUR WARRANTY AND MUST BE RETAINED AND PRODUCED IN THE EVENT OF A WARRANTY CLAIM

SonicAlert

1050 East Maple Rd.

Troy, MI 48083

Ph: 248 577 5400

Fax: 248 577 5433

www.sonicalert.com