

Assembly Instructions For The Daybed

Tools Needed:

Hammer For Light Tapping
Screwgun
#2 Square Drive Bit

Parts List:

Seat Assembly (1)
Back Assembly (1)
Right Arm Assembly (1)
Left Arm Assembly (1)
Front Legs (2)
Back Legs (2)

Hardware:

1/4" x 4-3/4" Bolts (6)
1/4" x 2-3/4" Bolts (6)
1-3/4" Screws (14)
Allen Wrench (1)

- Step 1** Lay out and identify all the parts and pieces.
- Step 2** Fasten the back to the seat. Align the predrilled holes on the bottom of the back with the threaded inserts in the back of the seat. Put two 4-3/4" bolts down through the back & turn into the inserts in the seat with the Allen wrench. **NOTE: Do not fully tighten these bolts until assembly is completed.**
- Step 3** Now fasten the legs to the bed. Note there are two front legs and two back legs. The front legs have threaded inserts side by side on one end & the back legs have inserts that are offset. Take a front leg and put it underneath on the inside of the bed frame, aligning the predrilled holes in the side of the bed with the inserts in the leg. Now insert a 2-3/4" bolt through the predrilled hole in the side of the bed closest to the front, turn into the insert & semi-tighten with the Allen wrench. Repeat on the other side. **(Note: Do not put any bolts in the other holes in the front at this point).**
- Step 4** Place the back legs on the inside of the bed frame & align the predrilled holes in the bed with the threaded inserts in the legs. Make sure the angled holes align, if they don't flip the legs the other way. Now insert a 2-3/4" bolt through the predrilled hole in the bottom point of the back assembly, turn into the insert and semi-tighten. Repeat on the other side.
- Step 5** Fasten the arms to the seat and back. Align the holes on the 2x4's on the bottom of the arms with the remaining predrilled holes in the side of the bed & the inserts in the legs. Put a 4-3/4" bolt through the holes in the 2x4's, on in through the bed & turn into the inserts. Semi-tighten with the Allen wrench. Now align the hole in the back of the arm with the threaded insert in the side of the back assembly, put another 2-3/4" bolt through & tighten. **(Note: If the holes do not align properly the back assembly can be moved back & forth).** Now take the 1-3/4" screws and insert in the predrilled holes in the slats on the arm and fasten to the side of the bed with the screwgun. (Extra screws are provided). Now attach the other arm & tighten all bolts.

