

Assembly Instructions For The New Hope Chair

Tools Needed:

Screwgun
#2 Square Drive Bit

Parts List:

Seat Assembly (1)
Back Assembly (1)
Front Legs (2)
Arms (2)
Front Leg Brace (1)

Hardware:

1/4" x 2" Bolts (10)
2-1/2" Screws (6)
Allen Wrench (1)

- Step 1** Attach the front legs to the seat assembly. (The braces belong on the outside of the legs). Align the predrilled holes in the legs with the threaded inserts in the side of the seat and insert two 2" bolts & turn into the inserts with the Allen wrench. Repeat on other side. **NOTE: Do not fully tighten any bolts until the chair is completely assembled.**
- Step 2** Place the arms on top of the front legs with the threaded inserts in the arms turned down. (The brace attached to the arms gets attached to the back of the chair). Align the holes in the small support brace on the front leg with the threaded inserts in the arm and insert two 2" bolts. Turn in with the Allen wrench but do not fully tighten. Repeat on other side.
- Step 3** Take the back assembly & place it inside the arms with the back slats against the notches cut out in the back of the arms. Align the holes in the vertical back supports with the metal inserts in the braces below the arms & insert two more 2" bolts through the back supports & turn into the inserts. Semi-tighten only.
- Step 4** Align the bottom front of the back assembly with the seat assembly so the slats are evenly spaced. Fasten the bottom back support strip to the chair legs with four 2-1/2" screws in the predrilled holes. The legs don't have predrilled holes as the screws are self drilling. **Do not overtighten.**
- Step 5** Take the leg brace & place it between the front legs. The brace is angled & will only fit one way. (If it does not fit between the legs loosen the bolts in the legs). Align the small predrilled holes in the side of the legs with the pilot holes in the ends of the brace & fasten with two 2-1/2" screws. **Do not overtighten.** Now fully tighten all the bolts with the Allen wrench.



Assembly Instructions For The New Hope Footstool

Tools Needed:

Screwgun
#2 Square Drive Bit
7/16" Wrench or Socket

Parts List:

Footstool Top (1)
Front Leg Assembly (1)
Back Leg Assembly (1)
Brace (1)

Hardware:

1/4" x 2" Bolts (4)
1/4" Washers (4)
1/4" Hex Nuts (4)
2-1/2" Screws (4)

- Step 1** Lay the footstool top upside down on a clean surface.
- Step 2** Place the leg assemblies inside the frame of the top. Align the predrilled holes in one end of the legs with the predrilled holes in the side of the frame. Insert the 2" bolts through the footstool frame & through the legs. Put a 1/4" washer & a 1/4" nut on the end of each bolt and tighten with the wrench or socket.
- Step 3** Put the brace between the leg assemblies. Center the brace with the predrilled holes in the leg assemblies & fasten with the 2-1/2" screws. Screws are self drilling & no holes are needed in ends of brace if properly aligned. **NOTE:** If footstool does not seem level on a solid surface loosen the nuts, level, & retighten the nuts.

